

ASSOCIATED PRODUCTS



FLIP UP SIGHTS

Can be used as primary or back-up sights.
#BGR: Low profile rear flip-up sight.
#BGF: Low profile front flip-up sight



RED-DOT SIGHT

#MRDS: Small and compatible with the Micro Roni.
#PBSS: Push button heavy duty sling swivel.



TACTICAL SLINGS & SLING SWIVEL

#OPS: One point sling
#PBSS: Push button heavy duty sling swivel.



POLYMER SUITCASE

#MIC-ROCASE: accepts the MIC-RONI and/or other accessories.



THUMB REST

#THR: Set of two. For left and right hand users



FLASHLIGHT

#MRFL: Integral front flashlight for both left and right users.



#MR-CMP Mic-Roni COMPENSATOR

Muzzle part
Color: Black
Made Of: Aluminum



#PMD Plus Muzzle Device

Color: Black
Made Of: Aluminum



MIC-ROCASE-F

Shaped-Foam
Gray Suitcase

THUMB REST, MAGAZINE AND SAFETY COVER



LEFT VIEW

THUMB RESTS - RIGHT AND LEFT

Slide the thumb rest (22) on the accessory side rail (3). Place it in position by using the locking-tooth.



RIGHT VIEW

Make sure that the locking-tooth (circled) is forward and the thumb rest (22) faces the same angle as illustrated above.



LEFT VIEW

EXTRA MAGAZINE

The extra magazine is held by pressure only. To use the extra magazine, pull it down while pushing with your thumb (circled) against the rear edge of the mag' carrier (18), or at the bottom of the trigger guard.
Note: The extra magazine carrier is not available with the stabilizer brace model.



RIGHT VIEW

TRIGGER GUARD SAFETY COVER

To secure the trigger, rotate the safety cover (19) on its hinge as illustrated above.

FLASHLIGHT INSTALATION



STEP 1

Push on both (left/right) locking-levers (21) and pull out the dummy-tube (green). Do not use the pistol extraction button (20) by mistake.

STEP 2

By rotating the flashlight 180°, you can choose which direction the activation push button (23) faces (left or right).

STEP 3

To replace the battery, by going through STEP-1 (above), unscrew the butt cap.

STOCK AND BRACE CONFIGURATIONS




NO NFA REQUIREMENTS

Operating the stabilizer brace

PLACING THE ARM
Put your arm into the brace. Use the Velcro to surround your arm and tighten it.

CLOSING
push the locking push-button (9) and swing the stock on its hinge. The stock does not locks against the body.



COMBAT PROVEN



MICRO GEN4X
RONI
THE ORIGINAL

USER MANUAL